



 PRODUCT-DETAILS

2000/7 US-507

Flush Mounted Inserts Intermediate switch 10 A



Product image
not available

General Information

Extended Product Type	2000/7 US-507
Product ID	2CKA001012A2130
EAN	4011395075487
Catalog Description	Flush Mounted Inserts Intermediate switch 10 A
Long Description	Can be illuminated by using a Illumination set as an accessory. The Illumination set is powered by the connected load. Suitability and maximum current for Illumination sets by the connected load must be ensured.

Installation

Instructions and Manuals	No document needed
Mounting Type	Flush Mounted
Type of Fastening	Mounting with Claw Mounting with Screw
Modular Components Included	Flush Mounted Insert with Mounting Plate

Environmental

Degree of Protection	IP20
----------------------	------

Technical

Data Sheet, Technical Information	No document needed
Function	Function lighting: Orientation
Number of Rocker Switches	1
Wiring Configuration	Intermediate switch
Actuator Type	Rocker/button
Illumination	Optional
Terminal Type	Screwless Terminals

Electrical

Rated Voltage (U_r)	250 V
Rated Current (I_n)	10 A
Power Watt	LEDi / CFLi 100 W

Design

Design Range	Basic55
Surface Finishing	Untreated Matt
Material	Thermoplastic Duroplast

Dimensions

Product Net Width	71 mm
Product Net Height	71 mm
Product Net Depth / Length	40 mm
Product Net Weight	60 g
Built-In Depth (t_2)	25 mm

Material Compliance

RoHS Information	2CKA200000E0128
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
REACH Declaration	2CKA309999E9999
REACH Information	False - does not contain substances > 0.1 mass percentage
REACH Date	20250218
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

Certificates and Declarations

Declaration of Conformity - CE	2CKA100000E0037
--------------------------------	-----------------

External Classifications and Standards

ETIM 9

EC001590 - Installation switch

eClass

V11.0 : 27144053

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA002148A0120	Extension of Claws		2148	1 piece
2CKA001731A1992	Accessories for Switch/push button, Single rocker alpine white - Reflex SI	2506-214-500	1	piece
2CKA001731A1891	Mechanical Controls for Switch/push button, Single rocker alpine white - Reflex SI	2506-214-507	1	piece
2CKA001731A1007	Mechanical Controls for Switch/push button, Single rocker black - Reflex SI	2506-215	1	piece
2CKA001731A4012	Rocker for Switch/push button, Single rocker red - Reflex SI	2506-217-101	1	piece
2CKA001731A2001	Accessories for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2506-212-500	1	piece
2CKA001731A1889	Mechanical Controls for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2506-212-507	1	piece
2CKA001751A3074	Accessories for Switch/push button, Single rocker studio white - Platform 63	1786-84-500	1	piece
2CKA001751A3077	Mechanical Controls for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	piece
2CKA001731A1593	Rocker for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2106-34	1	piece
2CKA001731A3991	Rocker for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2106-34-500	1	piece
2CKA001751A3145	Rocker for Switch/push button, Single rocker red - Platform 63	1786-12-82	1	piece
2CKA001751A3079	Mechanical Controls for Switch/push button, Single rocker anthracite - Platform 63	1786-81-500	1	piece
2CKA001751A3083	Accessories for Switch/push button, Single rocker ivory white - Platform 63	1786-82-500	1	piece
2CKA001751A3075	Accessories for Switch/push button, Single rocker aluminium silver - Platform 63	1786-83-500	1	piece
2CKA001751A3089	Accessories for Switch/push button, Single rocker studio white matt - Platform 63	1786-884-500	1	piece
2CKA001751A3094	Accessories for Switch/push button, Single rocker black matt - Platform 63	1786-885-500	1	piece
2CKA001731A1962	Rocker for Switch/push button, Single rocker brown - Allwetter 44 (IP 44)	2106-31	1	piece
2CKA001731A1775	Rocker for Switch/push button, Single rocker white - Allwetter 44 (IP 44)	2106-32	1	piece
2CKA001731A1997	Rocker for Switch/push button, Single rocker white - Allwetter 44 (IP 44)	2106-32-500	1	piece
2CKA001731A1963	Rocker for Switch/push button, Single rocker aluminium silver - Allwetter 44 (IP 44)	2106-33	1	piece
2CKA001731A1668	Rocker for Switch/push button, Single rocker anthracite - Allwetter 44 (IP 44)	2106-35	1	piece
2CKA001751A3081	Rocker for Switch/push button, Single rocker ivory - alpha	1786-22G-500	1	piece
2CKA001751A3078	Rocker for Switch/push button, Single rocker studio white - alpha	1786-24G-500	1	piece
2CKA001751A3090	Rocker for Switch/push button, Single rocker platinum - alpha	1786-20-500	1	piece
2CKA001751A3086	Rocker for Switch/push button, Single rocker bronze - alpha	1786-21-500	1	piece
2CKA001751A3080	Rocker for Switch/push button, Single rocker palladium - alpha	1786-260-500	1	piece
2CKA001751A3085	Rocker for Switch/push button, Single rocker titanium - alpha	1786-266-500	1	piece

2CKA001751A3093	Mechanical Controls for Switch/push button, Single rocker grey metallic - Platform 63	1786-803-500	1	piece
2CKA001434A0448	Rocker with neutral symbol, screwable Neutral symbol for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2546-212	1	piece
2CKA001434A0554	Rocker with neutral symbol, screwable Neutral symbol for Switch/push button, Single rocker alpine white - Reflex SI	2546-214	1	piece
2CKA001731A1996	Mechanical Controls Symbol "light" for Switch/push button, Single rocker alpine white - Reflex SI	2520 LI-214-500	1	piece
2CKA001731A0272	Rocker with legend Symbol "light" for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2520 LI-212	1	piece
2CKA001751A3190	Mechanical Controls Symbol "light" for Switch/push button, Single rocker studio white - Platform 63	2520 LI-84-500	1	piece
2CKA001751A3191	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	piece
2CKA001751A3186	Rocker with legend Symbol "light" for Switch/push button, Single rocker anthracite - Platform 63	2520 LI-81	1	piece
2CKA001751A3187	Rocker with legend Symbol "light" for Switch/push button, Single rocker ivory white - Platform 63	2520 LI-82	1	piece
2CKA001751A3188	Rocker with legend Symbol "light" for Switch/push button, Single rocker aluminium silver - Platform 63	2520 LI-83	1	piece
2CKA001751A3192	Rocker with legend Symbol "light" for Switch/push button, Single rocker studio white matt - Platform 63	2520 LI-884	1	piece
2CKA001751A3193	Rocker with legend Symbol "light" for Switch/push button, Single rocker black matt - Platform 63	2520 LI-885	1	piece
2CKA001731A0520	Rocker with labelling field for Switch/push button, Single rocker alpine white - Reflex SI	2506 N-214	1	piece
2CKA001731A0561	Rocker with labelling field for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2506 N-212	1	piece
2CKA001731A1643	Rocker with labelling field for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2106 N-34	1	piece
2CKA001731A1960	Rocker with labelling field for Switch/push button, Single rocker brown - Allwetter 44 (IP 44)	2106 N-31	1	piece
2CKA001731A1825	Rocker with labelling field for Switch/push button, Single rocker white - Allwetter 44 (IP 44)	2106 N-32	1	piece
2CKA001731A1961	Rocker with labelling field for Switch/push button, Single rocker aluminium silver - Allwetter 44 (IP 44)	2106 N-33	1	piece
2CKA001731A1718	Rocker with labelling field for Switch/push button, Single rocker anthracite - Allwetter 44 (IP 44)	2106 N-35	1	piece
2CKA001751A2540	Rocker with labelling field for Switch/push button, Single rocker ivory - alpha	1781-22G	1	piece
2CKA001751A2292	Rocker with labelling field for Switch/push button, Single rocker studio white - alpha	1781-24G	1	piece
2CKA001751A1666	Rocker with labelling field for Switch/push button, Single rocker platinum - alpha	1781-20	1	piece
2CKA001751A1757	Rocker with labelling field for Switch/push button, Single rocker bronze - alpha	1781-21	1	piece
2CKA001751A2833	Rocker with labelling field for Switch/push button, Single rocker titanium - alpha	1781-266	1	piece
2CKA001751A3185	Rocker for Switch/push button, Single rocker grey metallic - Platform 63	2520 LI-803	1	piece
2CKA001784A0545	Illumination set for Switch/push button Orange Neon lamp, 0.4 mA, 230 V red	8350	1	piece
2CKA001784A0552	Illumination set for Switch/push button Orange Neon lamp, 0.4 mA, 230 V red	8360	1	piece
2CKA001784A0779	Illumination set for Switch/push button White LED, 0.5 mA, 230 V red	8380-10	1	piece
2CKA001784A0788	Illumination set for Switch/push button White LED, 0.5 mA, 230 V red	8390-10	1	piece
2CKA001784A0782	Illumination set for Switch/push button Red LED, 0.5 mA, 230 V red	8380-12	1	piece

2CKA001784A0791	Illumination set for Switch/push button Red LED, 0.5 mA, 230 V red	8390-12	1	piece
2CKA001784A0785	Illumination set for Switch/push button Blue LED, 0.5 mA, 230 V red	8380-17	1	piece
2CKA001784A0794	Illumination set for Switch/push button Blue LED, 0.5 mA, 230 V red	8390-17	1	piece
2CKA001784A0560	Illumination set for Switch/push button Orange Neon lamp, 1 mA, 230 V yellow	8352	2	piece
2CKA001784A0586	Illumination set for Switch/push button Orange Neon lamp, 1 mA, 230 V yellow	8362	3	piece
2CKA001784A0578	Illumination set for Switch/push button Orange Neon lamp, 2 mA, 230 V white	8353	4	piece
2CKA001784A0594	Illumination set for Switch/push button Orange Neon lamp, 2 mA, 230 V white	8363	5	piece
2CKA001784A0780	Illumination set for Switch/push button White LED, 1 mA, 230 V yellow	8382-10	6	piece
2CKA001784A0789	Illumination set for Switch/push button White LED, 1 mA, 230 V yellow	8392-10	7	piece
2CKA001784A0783	Illumination set for Switch/push button Red LED, 1 mA, 230 V yellow	8382-12	8	piece
2CKA001784A0792	Illumination set for Switch/push button Red LED, 1 mA, 230 V yellow	8392-12	9	piece
2CKA001784A0786	Illumination set for Switch/push button Blue LED, 1 mA, 230 V yellow	8382-17	10	piece
2CKA001784A0795	Illumination set for Switch/push button Blue LED, 1 mA, 230 V yellow	8392-17	11	piece
2CKA001784A0781	Illumination set for Switch/push button White LED, 2 mA, 230 V white	8383-10	12	piece
2CKA001784A0790	Illumination set for Switch/push button White LED, 2 mA, 230 V white	8393-10	13	piece
2CKA001784A0784	Illumination set for Switch/push button Red LED, 2 mA, 230 V white	8383-12	14	piece
2CKA001784A0793	Illumination set for Switch/push button Red LED, 2 mA, 230 V white	8393-12	15	piece
2CKA001784A0787	Illumination set for Switch/push button Blue LED, 2 mA, 230 V white	8383-17	16	piece
2CKA001784A0796	Illumination set for Switch/push button Blue LED, 2 mA, 230 V white	8393-17	17	piece
2CKA001751A3151	Mechanical Controls with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 N-84-500	1	piece
2CKA001751A3091	Mechanical Controls with Small Red Calotte for Switch/push button, Single rocker studio white - Platform 63	1789-84-500	1	piece
2CKA001751A3152	Rocker with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	piece
2CKA001751A2957	Rocker with Small Red Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789-866	1	piece
2CKA001751A3147	Rocker with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 N-81	1	piece
2CKA001751A3148	Rocker with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 N-82	1	piece
2CKA001751A2928	Rocker with Small Red Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789-81	1	piece
2CKA001751A2813	Rocker with Small Red Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789-82	1	piece
2CKA001751A3149	Rocker with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 N-83	1	piece
2CKA001751A3153	Rocker with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 N-884	1	piece
2CKA001751A3154	Rocker with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 N-885	1	piece

2CKA001751A2945	Rocker with Small Red Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789-83	1	piece
2CKA001751A3033	Rocker with Small Red Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789-884	1	piece
2CKA001751A3047	Rocker with Small Red Calotte for Switch/push button, Single rocker black matt - Platform 63	1789-885	1	piece
2CKA001751A2508	Rocker for Switch/push button, Single rocker ivory - alpha	1787-22G	1	piece
2CKA001751A2177	Rocker for Switch/push button, Single rocker studio white - alpha	1787-24G	1	piece
2CKA001751A2490	Rocker with Small Red Calotte for Switch/push button, Single rocker ivory - alpha	1789-22G	1	piece
2CKA001751A2102	Rocker with Small Red Calotte for Switch/push button, Single rocker studio white - alpha	1789-24G	1	piece
2CKA001751A2045	Rocker for Switch/push button, Single rocker platinum - alpha	1787-20	1	piece
2CKA001751A2052	Rocker for Switch/push button, Single rocker bronze - alpha	1787-21	1	piece
2CKA001751A2824	Rocker for Switch/push button, Single rocker palladium - alpha	1787-260	1	piece
2CKA001751A2835	Rocker for Switch/push button, Single rocker titanium - alpha	1787-266	1	piece
2CKA001751A1625	Rocker with Small Red Calotte for Switch/push button, Single rocker platinum - alpha	1789-20	1	piece
2CKA001751A1716	Rocker with Small Red Calotte for Switch/push button, Single rocker bronze - alpha	1789-21	1	piece
2CKA001751A2825	Rocker with Small Red Calotte for Switch/push button, Single rocker palladium - alpha	1789-260	1	piece
2CKA001751A2836	Rocker with Small Red Calotte for Switch/push button, Single rocker titanium - alpha	1789-266	1	piece
2CKA001751A3146	Rocker with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 N-803	1	piece
2CKA001751A3013	Rocker with Small Red Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789-803	1	piece
2CKA001751A3084	Mechanical Controls Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - Platform 63	1789 LI-84-500	1	piece
2CKA001751A2958	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	piece
2CKA001751A2931	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker anthracite - Platform 63	1789 LI-81	1	piece
2CKA001751A2745	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker ivory white - Platform 63	1789 LI-82	1	piece
2CKA001751A2951	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker aluminium silver - Platform 63	1789 LI-83	1	piece
2CKA001751A3031	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white matt - Platform 63	1789 LI-884	1	piece
2CKA001751A3045	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker black matt - Platform 63	1789 LI-885	1	piece
2CKA001751A2516	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker ivory - alpha	1789 LI-22G	1	piece
2CKA001751A2201	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker studio white - alpha	1789 LI-24G	1	piece
2CKA001751A1633	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker platinum - alpha	1789 LI-20	1	piece

2CKA001751A1724	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker bronze - alpha	1789 LI-21	1	piece
2CKA001751A2828	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker palladium - alpha	1789 LI-260	1	piece
2CKA001751A2839	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker titanium - alpha	1789 LI-266	1	piece
2CKA001751A3014	Rocker with legend Symbol "light" with Small Transparent Calotte for Switch/push button, Single rocker grey metallic - Platform 63	1789 LI-803	1	piece
2CKA001731A0751	Rocker with labelling field for Switch/push button, Single rocker alpine white - Reflex SI	2510 N-214	1	piece
2CKA001731A1452	Rocker with labelling field for Switch/push button, Single rocker alpine white - Reflex SI	2510 NLI-214	1	piece
2CKA001731A0405	Mechanical Controls for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2510 N-212-500	1	piece
2CKA001731A1445	Rocker with labelling field for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2510 NLI-212	1	piece
2CKA001731A1877	Rocker with labelling field for Switch/push button, Single rocker studio white - Platform 63	1764 NLI-84	1	piece
2CKA001731A1953	Rocker with labelling field for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1764 NLI-866	1	piece
2CKA001731A4011	Rocker with labelling field for Switch/push button, Single rocker red - Platform 63	1764 NLI-12-82-101	1	piece
2CKA001731A4007	Rocker with labelling field for Switch/push button, Single rocker green - Platform 63	1764 NLI-13-82	1	piece
2CKA001731A1552	Rocker with labelling field for Switch/push button, Single rocker anthracite - Platform 63	1764 NLI-81	1	piece
2CKA001731A1876	Rocker with labelling field for Switch/push button, Single rocker ivory white - Platform 63	1764 NLI-82	1	piece
2CKA001731A1948	Rocker with labelling field for Switch/push button, Single rocker aluminium silver - Platform 63	1764 NLI-83	1	piece
2CKA001731A1985	Rocker with labelling field for Switch/push button, Single rocker studio white matt - Platform 63	1764 NLI-884	1	piece
2CKA001731A1982	Rocker with labelling field for Switch/push button, Single rocker black matt - Platform 63	1764 NLI-885	1	piece
2CKA001731A1858	Rocker with labelling field for Switch/push button, Single rocker ivory - alpha	1764 NLI-22G	1	piece
2CKA001731A1569	Rocker with labelling field for Switch/push button, Single rocker studio white - alpha	1764 NLI-24G	1	piece
2CKA001731A1975	Rocker with labelling field for Switch/push button, Single rocker grey metallic - Platform 63	1764 NLI-803	1	piece
2CKA001731A0900	Rocker with Red Calotte for Switch/push button, Single rocker alpine white - Reflex SI	2509-214	1	piece
2CKA001731A1995	Mechanical Controls with Red Calotte for Switch/push button, Single rocker alpine white - Reflex SI	2509-214-500	1	piece
2CKA001731A1994	Mechanical Controls for Switch/push button, Single rocker alpine white - Reflex SI	2520-214-500	1	piece
2CKA001731A0355	Mechanical Controls with Red Calotte for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2509-212-500	1	piece
2CKA001731A2000	Mechanical Controls for Switch/push button, Single rocker white - Busch-Duro 2000 SI	2520-212-500	1	piece
2CKA001731A1916	Rocker open for red pull button calotte for Push switch, Pull cord studio white - Platform 63	1720-84	1	piece
2CKA001731A1954	Rocker open for red pull button calotte for Push switch, Pull cord stainless steel - Pure Stainless Steel	1720-866	1	piece
2CKA001731A1734	Rocker with red calotte with Red Calotte for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2107-34	1	piece
2CKA001731A1635	Rocker for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2120-34	1	piece
2CKA001731A1998	Mechanical Controls for Switch/push button, Single rocker alpine white - Allwetter 44 (IP 44)	2120-34-500	1	piece

2CKA001731A1914	Rocker open for red pull button calotte for Push switch, Pull cord anthracite - Platform 63	1720-81	1	piece
2CKA001731A1915	Rocker open for red pull button calotte for Push switch, Pull cord ivory white - Platform 63	1720-82	1	piece
2CKA001731A1949	Rocker open for red pull button calotte for Push switch, Pull cord aluminium silver - Platform 63	1720-83	1	piece
2CKA001731A1979	Rocker open for red pull button calotte for Push switch, Pull cord studio white matt - Platform 63	1720-884	1	piece
2CKA001731A1981	Rocker open for red pull button calotte for Push switch, Pull cord black matt - Platform 63	1720-885	1	piece
2CKA001731A1964	Rocker with red calotte with Red Calotte for Switch/push button, Single rocker brown - Allwetter 44 (IP 44)	2107-31	1	piece
2CKA001731A1833	Rocker with red calotte with Red Calotte for Switch/push button, Single rocker white - Allwetter 44 (IP 44)	2107-32	1	piece
2CKA001731A1965	Rocker with red calotte with Red Calotte for Switch/push button, Single rocker aluminium silver - Allwetter 44 (IP 44)	2107-33	1	piece
2CKA001731A1742	Rocker with red calotte with Red Calotte for Switch/push button, Single rocker anthracite - Allwetter 44 (IP 44)	2107-35	1	piece
2CKA001731A1968	Rocker for Switch/push button, Single rocker brown - Allwetter 44 (IP 44)	2120-31	1	piece
2CKA001731A1817	Rocker for Switch/push button, Single rocker white - Allwetter 44 (IP 44)	2120-32	1	piece
2CKA001731A1969	Rocker for Switch/push button, Single rocker aluminium silver - Allwetter 44 (IP 44)	2120-33	1	piece
2CKA001731A1700	Rocker with legend for Switch/push button, Single rocker anthracite - Allwetter 44 (IP 44)	2120-35	1	piece
2CKA001725A1536	Cover frame 1gang alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	Cover frame 1gang alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1552	Cover frame 1gang white - Busch-Duro 2000 SI	2511-212-500	1	piece
2CKA001725A1463	Cover frame 1gang white - Busch-Duro 2000 SI	2511-212-507	1	piece
2CKA001754A4498	Cover frame 1gang studio white - future linear	1721-184K-500	1	piece
2CKA001754A4500	Cover frame 1-gang(s) stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001730A0191	Cover frame 1-gang(s) alpine white - Allwetter 44 (IP 44)	2101-34	1	piece
2CKA001730A0281	Cover frame 1-gang(s) alpine white - Allwetter 44 (IP 44)	2101-34-500	1	piece
2CKA001754A4173	Cover frame 1gang studio white - future	1721-184	1	piece
2CKA001754A4504	Cover frame 1gang studio white - future	1721-184-500	1	piece
2CKA001754A4331	Cover frame 1gang studio white - Busch-axcent	1721-284	1	piece
2CKA001754A4437	Cover frame 1gang white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4536	Cover frame 1-gang(s) studio white - solo	1721-84-500	1	piece
2CKA001754A4442	Cover frame 1-gang(s) white glass - carat	1721-811	1	piece
2CKA001754A4600	Cover frame 1-gang(s) ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A2965	Cover frame 1gang studio white - alpha exclusive	1721 KA-24G	1	piece
2CKA001754A4503	Cover frame 1gang studio white - alpha nea	1721-24G-500	1	piece
2CKA001725A1539	Cover frame 1gang alpine white - Reflex SI Linear	2511-214K-102-500	1	piece
2CKA001725A1549	Cover frame 1gang white - Busch-Duro 2000 SI Linear	2511-212K-102-500	1	piece
2CKA001754A4506	Cover frame 1gang ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4168	Cover frame 1gang ivory white - future	1721-182	1	piece
2CKA001754A4409	Cover frame 1gang black - Busch-axcent	1721-281	1	piece
2CKA001730A0258	Cover frame 1-gang(s) white - Allwetter 44 (IP 44)	2101-32	1	piece
2CKA001730A0282	Cover frame 1-gang(s) white - Allwetter 44 (IP 44)	2101-32-500	1	piece
2CKA001754A4800	Cover frame 1gang glass black - Busch-axcent pur	1721-245	1	piece
2CKA001754A4322	Cover frame 1-gang(s) glass black - carat	1721-825	1	piece
2CKA001754A4605	Cover frame 1-gang(s) anthracite - Busch-Dynasty	1721-831-500	1	piece

2CKA001754A4512	Cover frame 1gang ivory - alpha nea	1721-22G-500	1	piece
2CKA001754A4240	Cover frame 1gang anthracite - future linear	1721-181K	1	piece
2CKA001730A0275	Cover frame 1-gang(s) brown - Allwetter 44 (IP 44)	2101-31	1	piece
2CKA001754A4538	Cover frame 1-gang(s) chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4820	Cover frame 1-gang(s) porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4373	Cover frame 1gang platinum - alpha exclusive	1721 KA-20	1	piece
2CKA001730A0276	Cover frame 1-gang(s) aluminium silver - Allwetter 44 (IP 44)	2101-33	1	piece
2CKA001754A4535	Cover frame 1-gang(s) chrome matt - solo	1721-80-500	1	piece
2CKA001754A4254	Cover frame 1-gang(s) stainless steel - carat	1721-860	1	piece
2CKA001754A4382	Cover frame 1gang bronze - alpha exclusive	1721 KA-21	1	piece
2CKA001754A4529	Cover frame 1gang aluminium silver - future linear	1721-183K-500	1	piece
2CKA001730A0225	Cover frame 1-gang(s) anthracite - Allwetter 44 (IP 44)	2101-35	1	piece
2CKA001754A4360	Cover frame 1-gang(s) chrome - carat	1721-826-101	1	piece
2CKA001754A4509	Cover frame 1gang titanium - alpha exclusive	1721 KA-266-500	1	piece
2CKA001754A4531	Cover frame 1gang studio white matt - future linear - matt	1721-884K-500	1	piece
2CKA001754A4356	Cover frame 1-gang(s) gold - carat	1721-823-101	1	piece
2CKA001754A4532	Cover frame 1gang black matt - future linear - matt	1721-885K-500	1	piece
2CKA001754A4258	Cover frame 1-gang(s) bronze - carat	1721-821	1	piece
2CKA001754A4334	Cover frame 1gang yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4775	Cover frame 1gang glass purple - Busch-axcent pur	1721-223	1	piece
2CKA001754A4560	Cover frame 1-gang(s) polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4521	Cover frame 1gang platinum - alpha nea	1721-20-500	1	piece
2CKA001754A4337	Cover frame 1gang green - Busch-axcent	1721-286	1	piece
2CKA001754A4760	Cover frame 1gang glass sun - Busch-axcent pur	1721-225	1	piece
2CKA001754A4570	Cover frame 1-gang(s) polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4522	Cover frame 1gang bronze - alpha nea	1721-21-500	1	piece
2CKA001754A4340	Cover frame 1gang red - Busch-axcent	1721-287	1	piece
2CKA001754A4770	Cover frame 1gang glass avocado - Busch-axcent pur	1721-226	1	piece
2CKA001754A4565	Cover frame 1-gang(s) polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4391	Cover frame 1gang titanium - alpha nea	1721-266	1	piece
2CKA001754A4343	Cover frame 1gang blue - Busch-axcent	1721-288	1	piece
2CKA001754A4765	Cover frame 1gang glass coral - Busch-axcent pur	1721-227	1	piece
2CKA001754A4575	Cover frame 1-gang(s) polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4755	Cover frame 1gang glass ocean - Busch-axcent pur	1721-228	1	piece
2CKA001754A4780	Cover frame 1gang glass oyster - Busch-axcent pur	1721-229	1	piece
2CKA001754A4688	Cover frame 1gang platinum - Busch-axcent pur	1721-270-500	1	piece
2CKA001754A4580	Cover frame 1-gang(s) antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4708	Cover frame 1gang black matt - Busch-axcent pur	1721-275-500	1	piece
2CKA001754A4590	Cover frame 1-gang(s) antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4698	Cover frame 1gang titanium - Busch-axcent pur	1721-276-500	1	piece
2CKA001754A4585	Cover frame 1-gang(s) antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4595	Cover frame 1-gang(s) antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4790	Cover frame 1gang paper brown - Busch-axcent pur	1721-243	1	piece
2CKA001754A4785	Cover frame 1gang paper blue - Busch-axcent pur	1721-248	1	piece

2CKA001754A4805	Cover frame 1gang slate grey - Busch-axcent pur	1721-290	1	piece
2CKA001754A4795	Cover frame 1gang concrete grey - Busch-axcent pur	1721-298	1	piece
2CKA001725A1009	Cover frame with legend 1gang alpine white - Reflex SI	2511 JH-214	1	piece
2CKA001725A0662	Cover frame with legend 1gang white - Busch-Duro 2000 SI	2511 JH-212	1	piece
2CKA001725A1033	Cover frame 1gang black - Reflex SI	2511-215	1	piece
2CKA001725A1563	Cover frame 1gang red - Reflex SI	2511-217-101	1	piece
2CKA001725A1564	Cover frame 1gang red - Reflex SI Linear	2511-217K-103	1	piece
2CKA001754A4713	Cover frame 1gang red - future linear	1721-12-182K-101	1	piece
2CKA001754A4516	Cover frame 1gang white - Busch-Duro 2000 SI	1721 NS-212-500	1	piece
2CKA001754A4527	Cover frame 1gang studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4065	Cover frame with labelling field, horizontal 1gang studio white - alpha exclusive	1721 NSKA-24G	1	piece
2CKA001754A4496	Cover frame 1gang alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4497	Cover frame 1gang alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A4093	Cover frame with labelling field, horizontal 1gang white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece
2CKA001725A1537	Cover frame 2gang alpine white - Reflex SI	2512-214-500	1	piece
2CKA001725A1466	Cover frame 2gang alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1553	Cover frame 2gang white - Busch-Duro 2000 SI	2512-212-500	1	piece
2CKA001725A1465	Cover frame 2gang white - Busch-Duro 2000 SI	2512-212-507	1	piece
2CKA001754A4499	Cover frame 2gang studio white - future linear	1722-184K-500	1	piece
2CKA001754A4501	Cover frame 2-gang(s) stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001730A0209	Cover frame 2-gang(s) alpine white - Allwetter 44 (IP 44)	2102-34	1	piece
2CKA001730A0283	Cover frame 2-gang(s) alpine white - Allwetter 44 (IP 44)	2102-34-500	1	piece
2CKA001754A4174	Cover frame 2gang studio white - future	1722-184	1	piece
2CKA001754A4508	Cover frame 2gang studio white - future	1722-184-500	1	piece
2CKA001754A4332	Cover frame 2gang studio white - Busch-axcent	1722-284	1	piece
2CKA001754A4438	Cover frame 2gang white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4539	Cover frame 2-gang(s) studio white - solo	1722-84-500	1	piece
2CKA001754A4443	Cover frame 2-gang(s) white glass - carat	1722-811	1	piece
2CKA001754A4601	Cover frame 2-gang(s) ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A2999	Cover frame 2gang studio white - alpha exclusive	1722 KA-24G	1	piece
2CKA001754A4511	Cover frame 2gang studio white - alpha nea	1722-24G-500	1	piece
2CKA001754A3054	Cover frame 2gang studio white - alpha exclusive	1732 KA-24G	1	piece
2CKA001754A4067	Cover frame with labelling field, vertical 2gang studio white - alpha exclusive	1732 NSKA-24G	1	piece
2CKA001754A4528	Cover frame 2gang studio white - alpha nea	1732-24G-500	1	piece
2CKA001725A1540	Cover frame 2gang alpine white - Reflex SI Linear	2512-214K-102-500	1	piece
2CKA001725A1550	Cover frame 2gang white - Busch-Duro 2000 SI Linear	2512-212K-102-500	1	piece
2CKA001754A4231	Cover frame 2gang ivory white - future linear	1722-182K	1	piece
2CKA001754A4169	Cover frame 2gang ivory white - future	1722-182	1	piece
2CKA001754A4410	Cover frame 2gang black - Busch-axcent	1722-281	1	piece
2CKA001730A0266	Cover frame 2-gang(s) white - Allwetter 44 (IP 44)	2102-32	1	piece
2CKA001730A0284	Cover frame 2-gang(s) white - Allwetter 44 (IP 44)	2102-32-500	1	piece
2CKA001754A4801	Cover frame 2gang glass black - Busch-axcent pur	1722-245	1	piece
2CKA001754A4323	Cover frame 2-gang(s) glass black - carat	1722-825	1	piece
2CKA001754A4606	Cover frame 2-gang(s) anthracite - Busch-Dynasty	1722-831-500	1	piece

2CKA001754A3849	Cover frame 2gang ivory - alpha exclusive	1722 KA-22G	1	piece
2CKA001754A3799	Cover frame 2gang ivory - alpha nea	1722-22G	1	piece
2CKA001754A3864	Cover frame 2gang ivory - alpha exclusive	1732 KA-22G	1	piece
2CKA001754A3757	Cover frame 2gang ivory - alpha nea	1732-22G	1	piece
2CKA001754A4241	Cover frame 2gang anthracite - future linear	1722-181K	1	piece
2CKA001730A0277	Cover frame 2-gang(s) brown - Allwetter 44 (IP 44)	2102-31	1	piece
2CKA001754A4327	Cover frame 2-gang(s) chrome gloss - solo	1722-80G	1	piece
2CKA001754A4821	Cover frame 2-gang(s) porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4374	Cover frame 2gang platinum - alpha exclusive	1722 KA-20	1	piece
2CKA001754A4375	Cover frame 2gang platinum - alpha exclusive	1732 KA-20	1	piece
2CKA001730A0278	Cover frame 2-gang(s) aluminium silver - Allwetter 44 (IP 44)	2102-33	1	piece
2CKA001754A4537	Cover frame 2-gang(s) chrome matt - solo	1722-80-500	1	piece
2CKA001754A4255	Cover frame 2-gang(s) stainless steel - carat	1722-860	1	piece
2CKA001754A4383	Cover frame 2gang bronze - alpha exclusive	1722 KA-21	1	piece
2CKA001754A4384	Cover frame 2gang bronze - alpha exclusive	1732 KA-21	1	piece
2CKA001754A4530	Cover frame 2gang aluminium silver - future linear	1722-183K-500	1	piece
2CKA001730A0233	Cover frame 2-gang(s) anthracite - Allwetter 44 (IP 44)	2102-35	1	piece
2CKA001754A4361	Cover frame 2-gang(s) chrome - carat	1722-826-101	1	piece
2CKA001754A4523	Cover frame 2gang titanium - alpha exclusive	1722 KA-266-500	1	piece
2CKA001754A4126	Cover frame 2gang titanium - alpha exclusive	1732 KA-266	1	piece
2CKA001754A4415	Cover frame 2gang studio white matt - future linear - matt	1722-884K	1	piece
2CKA001754A4357	Cover frame 2-gang(s) gold - carat	1722-823-101	1	piece
2CKA001754A4534	Cover frame 2gang black matt - future linear - matt	1722-885K-500	1	piece
2CKA001754A4259	Cover frame 2-gang(s) bronze - carat	1722-821	1	piece
2CKA001754A4335	Cover frame 2gang yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4776	Cover frame 2gang glass purple - Busch-axcent pur	1722-223	1	piece
2CKA001754A4561	Cover frame 2-gang(s) polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4524	Cover frame 2gang platinum - alpha nea	1722-20-500	1	piece
2CKA001754A1660	Cover frame 2gang platinum - alpha nea	1732-20	1	piece
2CKA001754A4338	Cover frame 2gang green - Busch-axcent	1722-286	1	piece
2CKA001754A4761	Cover frame 2gang glass sun - Busch-axcent pur	1722-225	1	piece
2CKA001754A4571	Cover frame 2-gang(s) polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A1710	Cover frame 2gang bronze - alpha nea	1722-21	1	piece
2CKA001754A1751	Cover frame 2gang bronze - alpha nea	1732-21	1	piece
2CKA001754A4341	Cover frame 2gang red - Busch-axcent	1722-287	1	piece
2CKA001754A4771	Cover frame 2gang glass avocado - Busch-axcent pur	1722-226	1	piece
2CKA001754A4566	Cover frame 2-gang(s) polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4392	Cover frame 2gang titanium - alpha nea	1722-266	1	piece
2CKA001754A4393	Cover frame 2gang titanium - alpha nea	1732-266	1	piece
2CKA001754A4344	Cover frame 2gang blue - Busch-axcent	1722-288	1	piece
2CKA001754A4766	Cover frame 2gang glass coral - Busch-axcent pur	1722-227	1	piece
2CKA001754A4576	Cover frame 2-gang(s) polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4756	Cover frame 2gang glass ocean - Busch-axcent pur	1722-228	1	piece
2CKA001754A4781	Cover frame 2gang glass oyster - Busch-axcent pur	1722-229	1	piece
2CKA001754A4689	Cover frame 2gang platinum - Busch-axcent pur	1722-270-500	1	piece
2CKA001754A4581	Cover frame 2-gang(s) antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4709	Cover frame 2gang black matt - Busch-axcent pur	1722-275-500	1	piece

2CKA001754A4591	Cover frame 2-gang(s) antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4699	Cover frame 2gang titanium - Busch-axcent pur	1722-276-500	1	piece
2CKA001754A4586	Cover frame 2-gang(s) antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4596	Cover frame 2-gang(s) antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4791	Cover frame 2gang paper brown - Busch-axcent pur	1722-243	1	piece
2CKA001754A4786	Cover frame 2gang paper blue - Busch-axcent pur	1722-248	1	piece
2CKA001754A4806	Cover frame 2gang slate grey - Busch-axcent pur	1722-290	1	piece
2CKA001754A4796	Cover frame 2gang concrete grey - Busch-axcent pur	1722-298	1	piece
2CKA001754A4117	Cover frame 2gang palladium - alpha exclusive	1732 KA-260	1	piece
2CKA001754A4402	Cover frame 2gang palladium - alpha nea	1732-260	1	piece
2CKA001725A1066	Cover frame 2gang black - Reflex SI	2512-215	1	piece
2CKA001725A1565	Cover frame 2gang red - Reflex SI	2512-217-101	1	piece
2CKA001725A1566	Cover frame 2gang red - Reflex SI Linear	2512-217K-103	1	piece
2CKA001754A4714	Cover frame 2gang red - future linear	1722-12-182K-101	1	piece
2CKA001754A2239	Cover frame with labelling field, vertical 2gang white - Busch-Duro 2000 SI	1722 NS-212	1	piece
2CKA001754A2213	Cover frame with labelling field, horizontal 2gang white - Busch-Duro 2000 SI	1732 NS-212	1	piece
2CKA001754A4368	Cover frame with labelling field, horizontal 2gang studio white - future linear	1732-184 NSK	1	piece
2CKA001754A4066	Cover frame with labelling field, horizontal 2gang studio white - alpha exclusive	1722 NSKA-24G	1	piece
2CKA001754A2163	Cover frame with labelling field, vertical 2gang alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4059	Cover frame with labelling field, vertical 2gang alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A4060	Cover frame with labelling field, horizontal 2gang alpine white - Reflex SI Linear	1732 NSKA-214	1	piece
2CKA001754A4094	Cover frame with labelling field, vertical 2gang white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A4095	Cover frame with labelling field, horizontal 2gang white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001725A1538	Cover frame 3gang alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1554	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-500	1	piece
2CKA001725A0639	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-506	1	piece
2CKA001725A1468	Cover frame 3gang white - Busch-Duro 2000 SI	2513-212-507	1	piece
2CKA001754A4502	Cover frame 3gang studio white - future linear	1723-184K-500	1	piece
2CKA001754A4319	Cover frame 3-gang(s) stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001730A0217	Cover frame 3-gang(s) alpine white - Allwetter 44 (IP 44)	2103-34	1	piece
2CKA001754A4175	Cover frame 3gang studio white - future	1723-184	1	piece
2CKA001754A4333	Cover frame 3gang studio white - Busch-axcent	1723-284	1	piece
2CKA001754A4439	Cover frame 3gang white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4541	Cover frame 3-gang(s) studio white - solo	1723-84-500	1	piece
2CKA001754A4444	Cover frame 3-gang(s) white glass - carat	1723-811	1	piece
2CKA001754A4602	Cover frame 3-gang(s) ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A3021	Cover frame 3gang studio white - alpha exclusive	1723 KA-24G	1	piece
2CKA001754A4518	Cover frame 3gang studio white - alpha nea	1723-24G-500	1	piece
2CKA001754A3088	Cover frame 3gang studio white - alpha exclusive	1733 KA-24G	1	piece
2CKA001754A4069	Cover frame with labelling field, vertical 3gang studio white - alpha exclusive	1733 NSKA-24G	1	piece
2CKA001754A2734	Cover frame 3gang studio white - alpha nea	1733-24G	1	piece
2CKA001725A1541	Cover frame 3gang alpine white - Reflex SI Linear	2513-214K-102-500	1	piece

2CKA001725A1551	Cover frame 3gang white - Busch-Duro 2000 SI2513-212K-102 Linear -500	1723-182K	1	piece
2CKA001754A4232	Cover frame 3gang ivory white - future linear	1723-182	1	piece
2CKA001754A4170	Cover frame 3gang ivory white - future	1723-281	1	piece
2CKA001754A4411	Cover frame 3gang black - Busch-axcent	2103-32	1	piece
2CKA001730A0274	Cover frame 3-gang(s) white - Allwetter 44 (IP 44)	1723-245	1	piece
2CKA001754A4802	Cover frame 3gang glass black - Busch-axcent pur	1723-825	1	piece
2CKA001754A4324	Cover frame 3-gang(s) glass black - carat	1723-831-500	1	piece
2CKA001754A4607	Cover frame 3-gang(s) anthracite - Busch- Dynasty	1723 KA-22G	1	piece
2CKA001754A3856	Cover frame 3gang ivory - alpha exclusive	1723-22G	1	piece
2CKA001754A3807	Cover frame 3gang ivory - alpha nea	1733 KA-22G	1	piece
2CKA001754A3872	Cover frame 3gang ivory - alpha exclusive	1733-22G	1	piece
2CKA001754A3765	Cover frame 3gang ivory - alpha nea	1723-181K	1	piece
2CKA001754A4242	Cover frame 3gang anthracite - future linear	2103-31	1	piece
2CKA001730A0279	Cover frame 3-gang(s) brown - Allwetter 44 (IP 44)	1723-80G	1	piece
2CKA001754A4328	Cover frame 3-gang(s) chrome gloss - solo	1723-815	1	piece
2CKA001754A4822	Cover frame 3-gang(s) porcelain anthracite - carat	1723 KA-20	1	piece
2CKA001754A4376	Cover frame 3gang platinum - alpha exclusive	1733 KA-20	1	piece
2CKA001754A4377	Cover frame 3gang platinum - alpha exclusive	2103-33	1	piece
2CKA001730A0280	Cover frame 3-gang(s) aluminium silver - Allwetter 44 (IP 44)	1723-80-500	1	piece
2CKA001754A4540	Cover frame 3-gang(s) chrome matt - solo	1723-860	1	piece
2CKA001754A4256	Cover frame 3-gang(s) stainless steel - carat	1723 KA-21	1	piece
2CKA001754A4385	Cover frame 3gang bronze - alpha exclusive	1733 KA-21	1	piece
2CKA001754A4386	Cover frame 3gang bronze - alpha exclusive	1723-183K-500	1	piece
2CKA001754A4533	Cover frame 3qang aluminium silver - future linear	2103-35	1	piece
2CKA001730A0241	Cover frame 3-gang(s) anthracite - Allwetter 44 (IP 44)	1723-826-101	1	piece
2CKA001754A4362	Cover frame 3-gang(s) chrome - carat	1723 KA-266	1	piece
2CKA001754A4127	Cover frame 3gang titanium - alpha exclusive	1733 KA-266	1	piece
2CKA001754A4128	Cover frame 3gang titanium - alpha exclusive	1723-884K	1	piece
2CKA001754A4416	Cover frame 3gang studio white matt - future linear - matt	1723-823-101	1	piece
2CKA001754A4358	Cover frame 3-gang(s) gold - carat	1723-885K	1	piece
2CKA001754A4421	Cover frame 3gang black matt - future linear - matt	1723-821	1	piece
2CKA001754A4260	Cover frame 3-gang(s) bronze - carat	1723-285	1	piece
2CKA001754A4336	Cover frame 3gang yellow - Busch-axcent	1723-223	1	piece
2CKA001754A4777	Cover frame 3gang glass purple - Busch-axcent pur	1723-838-500	1	piece
2CKA001754A4562	Cover frame 3-gang(s) polished brass ivory white - Busch-Dynasty	1723-20	1	piece
2CKA001754A1637	Cover frame 3gang platinum - alpha nea	1733-20	1	piece
2CKA001754A1678	Cover frame 3gang platinum - alpha nea	1723-286	1	piece
2CKA001754A4339	Cover frame 3gang green - Busch-axcent	1723-225	1	piece
2CKA001754A4762	Cover frame 3gang glass sun - Busch-axcent pur	1723-836-500	1	piece
2CKA001754A4572	Cover frame 3-gang(s) polished brass decor ivory white - Busch-Dynasty	1723-21	1	piece
2CKA001754A1728	Cover frame 3gang bronze - alpha nea	1733-21	1	piece
2CKA001754A1769	Cover frame 3gang bronze - alpha nea	1723-287	1	piece
2CKA001754A4342	Cover frame 3gang red - Busch-axcent	1723-226	1	piece
2CKA001754A4772	Cover frame 3gang glass avocado - Busch-axcent pur	1723-835-500	1	piece
2CKA001754A4567	Cover frame 3-gang(s) polished brass anthracite - Busch-Dynasty	1723-266	1	piece
2CKA001754A4394	Cover frame 3gang titanium - alpha nea	1733-266	1	piece
2CKA001754A4395	Cover frame 3gang titanium - alpha nea	1723-288	1	piece
2CKA001754A4345	Cover frame 3gang blue - Busch-axcent			

2CKA001754A4767	Cover frame 3gang glass coral - Busch-axcent pur	1723-227	1	piece
2CKA001754A4577	Cover frame 3-gang(s) polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4757	Cover frame 3gang glass ocean - Busch-axcent pur	1723-228	1	piece
2CKA001754A4782	Cover frame 3gang glass oyster - Busch-axcent pur	1723-229	1	piece
2CKA001754A4690	Cover frame 3gang platinum - Busch-axcent pur	1723-270-500	1	piece
2CKA001754A4582	Cover frame 3-gang(s) antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4710	Cover frame 3gang black matt - Busch-axcent pur	1723-275-500	1	piece
2CKA001754A4592	Cover frame 3-gang(s) antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4700	Cover frame 3gang titanium - Busch-axcent pur	1723-276-500	1	piece
2CKA001754A4587	Cover frame 3-gang(s) antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4597	Cover frame 3-gang(s) antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4792	Cover frame 3gang paper brown - Busch-axcent pur	1723-243	1	piece
2CKA001754A4787	Cover frame 3gang paper blue - Busch-axcent pur	1723-248	1	piece
2CKA001754A4807	Cover frame 3gang slate grey - Busch-axcent pur	1723-290	1	piece
2CKA001754A4797	Cover frame 3gang concrete grey - Busch-axcent pur	1723-298	1	piece
2CKA001754A4118	Cover frame 3gang palladium - alpha exclusive	1723 KA-260	1	piece
2CKA001754A4119	Cover frame 3gang palladium - alpha exclusive	1733 KA-260	1	piece
2CKA001725A1090	Cover frame 3gang black - Reflex SI	2513-215	1	piece
2CKA001754A3708	Cover frame with labelling field, vertical 3gang white - Busch-Duro 2000 SI	1723 NS-212	1	piece
2CKA001754A3716	Cover frame with labelling field, horizontal 3gang white - Busch-Duro 2000 SI	1733 NS-212	1	piece
2CKA001754A4366	Cover frame with labelling field, vertical 3gang studio white - future linear	1723-184 NSK	1	piece
2CKA001754A4369	Cover frame with labelling field, horizontal 3gang studio white - future linear	1733-184 NSK	1	piece
2CKA001754A4068	Cover frame with labelling field, horizontal 3gang studio white - alpha exclusive	1723 NSKA-24G	1	piece
2CKA001754A3724	Cover frame with labelling field, vertical 3gang alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A3732	Cover frame with labelling field, horizontal 3gang alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4061	Cover frame with labelling field, vertical 3gang alpine white - Reflex SI Linear	1723 NSKA-214	1	piece
2CKA001754A4062	Cover frame with labelling field, horizontal 3gang alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4096	Cover frame with labelling field, vertical 3gang white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	piece
2CKA001754A4097	Cover frame with labelling field, horizontal 3gang white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001725A1543	Cover frame 4gang alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A0647	Cover frame 4gang white - Busch-Duro 2000 SI	2514-212-500	1	piece
2CKA001754A4238	Cover frame 4gang studio white - future linear	1724-184K	1	piece
2CKA001754A4320	Cover frame 4-gang(s) stainless steel - Pure Stainless Steel	1724-866K	1	piece
2CKA001754A4176	Cover frame 4gang studio white - future	1724-184	1	piece
2CKA001754A4346	Cover frame 4gang studio white - Busch-axcent	1724-284	1	piece
2CKA001754A4440	Cover frame 4gang white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4112	Cover frame 4-gang(s) studio white - solo	1724-84	1	piece
2CKA001754A4445	Cover frame 4-gang(s) white glass - carat	1724-811	1	piece
2CKA001754A4603	Cover frame 4-gang(s) ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001754A4155	Cover frame 4gang studio white - alpha exclusive	1724 KA-24G	1	piece
2CKA001754A2908	Cover frame 4gang studio white - alpha nea	1724-24G	1	piece

2CKA001754A4156	Cover frame 4gang studio white - alpha exclusive	1734 KA-24G	1	piece
2CKA001754A2809	Cover frame 4gang studio white - alpha nea	1734-24G	1	piece
2CKA001725A1497	Cover frame 4gang alpine white - Reflex SI Linear	2514-214K-102	1	piece
2CKA001725A1492	Cover frame 4gang white - Busch-Duro 2000 SI Linear	2514-212K-102	1	piece
2CKA001754A4233	Cover frame 4gang ivory white - future linear	1724-182K	1	piece
2CKA001754A4171	Cover frame 4gang ivory white - future	1724-182	1	piece
2CKA001754A4412	Cover frame 4gang black - Busch-axcent	1724-281	1	piece
2CKA001754A4803	Cover frame 4gang glass black - Busch-axcent pur	1724-245	1	piece
2CKA001754A4325	Cover frame 4-gang(s) glass black - carat	1724-825	1	piece
2CKA001754A4608	Cover frame 4-gang(s) anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001754A4151	Cover frame 4gang ivory - alpha exclusive	1724 KA-22G	1	piece
2CKA001754A3815	Cover frame 4gang ivory - alpha nea	1724-22G	1	piece
2CKA001754A4152	Cover frame 4gang ivory - alpha exclusive	1734 KA-22G	1	piece
2CKA001754A3773	Cover frame 4gang ivory - alpha nea	1734-22G	1	piece
2CKA001754A4243	Cover frame 4gang anthracite - future linear	1724-181K	1	piece
2CKA001754A4329	Cover frame 4-gang(s) chrome gloss - solo	1724-80G	1	piece
2CKA001754A4378	Cover frame 4gang platinum - alpha exclusive	1724 KA-20	1	piece
2CKA001754A4379	Cover frame 4gang platinum - alpha exclusive	1734 KA-20	1	piece
2CKA001754A4107	Cover frame 4-gang(s) chrome matt - solo	1724-80	1	piece
2CKA001754A4257	Cover frame 4-gang(s) stainless steel - carat	1724-860	1	piece
2CKA001754A4387	Cover frame 4gang bronze - alpha exclusive	1724 KA-21	1	piece
2CKA001754A4388	Cover frame 4gang bronze - alpha exclusive	1734 KA-21	1	piece
2CKA001754A4309	Cover frame 4gang aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4363	Cover frame 4-gang(s) chrome - carat	1724-826-101	1	piece
2CKA001754A4129	Cover frame 4gang titanium - alpha exclusive	1724 KA-266	1	piece
2CKA001754A4130	Cover frame 4gang titanium - alpha exclusive	1734 KA-266	1	piece
2CKA001754A4417	Cover frame 4gang studio white matt - future linear - matt	1724-884K	1	piece
2CKA001754A4359	Cover frame 4-gang(s) gold - carat	1724-823-101	1	piece
2CKA001754A4422	Cover frame 4gang black matt - future linear - matt	1724-885K	1	piece
2CKA001754A4261	Cover frame 4-gang(s) bronze - carat	1724-821	1	piece
2CKA001754A4348	Cover frame 4gang yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4778	Cover frame 4gang glass purple - Busch-axcent pur	1724-223	1	piece
2CKA001754A4563	Cover frame 4-gang(s) polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001754A1645	Cover frame 4gang platinum - alpha nea	1724-20	1	piece
2CKA001754A1686	Cover frame 4gang platinum - alpha nea	1734-20	1	piece
2CKA001754A4350	Cover frame 4gang green - Busch-axcent	1724-286	1	piece
2CKA001754A4763	Cover frame 4gang glass sun - Busch-axcent pur	1724-225	1	piece
2CKA001754A4573	Cover frame 4-gang(s) polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001754A1736	Cover frame 4gang bronze - alpha nea	1724-21	1	piece
2CKA001754A1777	Cover frame 4gang bronze - alpha nea	1734-21	1	piece
2CKA001754A4352	Cover frame 4gang red - Busch-axcent	1724-287	1	piece
2CKA001754A4773	Cover frame 4gang glass avocado - Busch-axcent pur	1724-226	1	piece
2CKA001754A4568	Cover frame 4-gang(s) polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece
2CKA001754A4396	Cover frame 4gang titanium - alpha nea	1724-266	1	piece
2CKA001754A4397	Cover frame 4gang titanium - alpha nea	1734-266	1	piece
2CKA001754A4354	Cover frame 4gang blue - Busch-axcent	1724-288	1	piece
2CKA001754A4768	Cover frame 4gang glass coral - Busch-axcent pur	1724-227	1	piece
2CKA001754A4578	Cover frame 4-gang(s) polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece
2CKA001754A4758	Cover frame 4gang glass ocean - Busch-axcent pur	1724-228	1	piece

2CKA001754A4783	Cover frame 4gang glass oyster - Busch-axcent pur	1724-229	1	piece
2CKA001754A4691	Cover frame 4gang platinum - Busch-axcent pur	1724-270-500	1	piece
2CKA001754A4583	Cover frame 4-gang(s) antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4711	Cover frame 4gang black matt - Busch-axcent pur	1724-275-500	1	piece
2CKA001754A4593	Cover frame 4-gang(s) antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4701	Cover frame 4gang titanium - Busch-axcent pur	1724-276-500	1	piece
2CKA001754A4588	Cover frame 4-gang(s) antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4598	Cover frame 4-gang(s) antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4793	Cover frame 4gang paper brown - Busch-axcent pur	1724-243	1	piece
2CKA001754A4788	Cover frame 4gang paper blue - Busch-axcent pur	1724-248	1	piece
2CKA001754A4808	Cover frame 4gang slate grey - Busch-axcent pur	1724-290	1	piece
2CKA001754A4798	Cover frame 4gang concrete grey - Busch-axcent pur	1724-298	1	piece
2CKA001754A4120	Cover frame 4gang palladium - alpha exclusive	1724 KA-260	1	piece
2CKA001754A4121	Cover frame 4gang palladium - alpha exclusive	1734 KA-260	1	piece
2CKA001754A4367	Cover frame with labelling field, vertical 4gang studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4370	Cover frame with labelling field, horizontal 4gang studio white - future linear	1734-184 NSK	1	piece
2CKA001754A4063	Cover frame with labelling field, vertical 4gang alpine white - Reflex SI Linear	1724 NSKA-214	1	piece
2CKA001754A4064	Cover frame with labelling field, horizontal 4gang alpine white - Reflex SI Linear	1734 NSKA-214	1	piece
2CKA001754A4098	Cover frame with labelling field, vertical 4gang white - Busch-Duro 2000 SI Linear	1724 NSKA-212	1	piece
2CKA001754A4099	Cover frame with labelling field, horizontal 4gang white - Busch-Duro 2000 SI Linear	1734 NSKA-212	1	piece
2CKA001725A0969	Cover frame 5gang alpine white - Reflex SI	2515-214	1	piece
2CKA001725A0654	Cover frame 5gang white - Busch-Duro 2000 SI	2515-212-500	1	piece
2CKA001725A1467	Cover frame 5gang white - Busch-Duro 2000 SI	2515-212-507	1	piece
2CKA001754A4517	Cover frame 5gang studio white - future linear	1725-184K-500	1	piece
2CKA001754A4321	Cover frame 5-gang(s) stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4177	Cover frame 5gang studio white - future	1725-184	1	piece
2CKA001754A4347	Cover frame 5gang studio white - Busch-axcent	1725-284	1	piece
2CKA001754A4441	Cover frame 5gang white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4113	Cover frame 5-gang(s) studio white - solo	1725-84	1	piece
2CKA001754A4604	Cover frame 5-gang(s) ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001754A4157	Cover frame 5gang studio white - alpha exclusive	1725 KA-24G	1	piece
2CKA001754A2932	Cover frame 5gang studio white - alpha nea	1725-24G	1	piece
2CKA001754A4158	Cover frame 5gang studio white - alpha exclusive	1735 KA-24G	1	piece
2CKA001754A2833	Cover frame 5gang studio white - alpha nea	1735-24G	1	piece
2CKA001725A1498	Cover frame 5gang alpine white - Reflex SI Linear	2515-214K-102	1	piece
2CKA001725A1493	Cover frame 5gang white - Busch-Duro 2000 SI Linear	2515-212K-102	1	piece
2CKA001754A4234	Cover frame 5gang ivory white - future linear	1725-182K	1	piece
2CKA001754A4172	Cover frame 5gang ivory white - future	1725-182	1	piece
2CKA001754A4413	Cover frame 5gang black - Busch-axcent	1725-281	1	piece
2CKA001754A4804	Cover frame 5gang glass black - Busch-axcent pur	1725-245	1	piece
2CKA001754A4609	Cover frame 5-gang(s) anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001754A4153	Cover frame 5gang ivory - alpha exclusive	1725 KA-22G	1	piece
2CKA001754A3823	Cover frame 5gang ivory - alpha nea	1725-22G	1	piece
2CKA001754A4154	Cover frame 5gang ivory - alpha exclusive	1735 KA-22G	1	piece
2CKA001754A3781	Cover frame 5gang ivory - alpha nea	1735-22G	1	piece

2CKA001754A4244	Cover frame 5gang anthracite - future linear	1725-181K	1	piece
2CKA001754A4330	Cover frame 5-gang(s) chrome gloss - solo	1725-80G	1	piece
2CKA001754A4380	Cover frame 5gang platinum - alpha exclusive	1725 KA-20	1	piece
2CKA001754A4381	Cover frame 5gang platinum - alpha exclusive	1735 KA-20	1	piece
2CKA001754A4108	Cover frame 5-gang(s) chrome matt - solo	1725-80	1	piece
2CKA001754A4389	Cover frame 5gang bronze - alpha exclusive	1725 KA-21	1	piece
2CKA001754A4390	Cover frame 5gang bronze - alpha exclusive	1735 KA-21	1	piece
2CKA001754A4310	Cover frame 5gang aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4131	Cover frame 5gang titanium - alpha exclusive	1725 KA-266	1	piece
2CKA001754A4132	Cover frame 5gang titanium - alpha exclusive	1735 KA-266	1	piece
2CKA001754A4418	Cover frame 5gang studio white matt - future linear - matt	1725-884K	1	piece
2CKA001754A4423	Cover frame 5gang black matt - future linear - matt	1725-885K	1	piece
2CKA001754A4349	Cover frame 5gang yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4779	Cover frame 5gang glass purple - Busch-axcent pur	1725-223	1	piece
2CKA001754A4564	Cover frame 5-gang(s) polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001754A1652	Cover frame 5gang platinum - alpha nea	1725-20	1	piece
2CKA001754A1694	Cover frame 5gang platinum - alpha nea	1735-20	1	piece
2CKA001754A4351	Cover frame 5gang green - Busch-axcent	1725-286	1	piece
2CKA001754A4764	Cover frame 5gang glass sun - Busch-axcent pur	1725-225	1	piece
2CKA001754A4574	Cover frame 5-gang(s) polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece
2CKA001754A1744	Cover frame 5gang bronze - alpha nea	1725-21	1	piece
2CKA001754A1785	Cover frame 5gang bronze - alpha nea	1735-21	1	piece
2CKA001754A4353	Cover frame 5gang red - Busch-axcent	1725-287	1	piece
2CKA001754A4774	Cover frame 5gang glass avocado - Busch-axcent pur	1725-226	1	piece
2CKA001754A4569	Cover frame 5-gang(s) polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece
2CKA001754A4398	Cover frame 5gang titanium - alpha nea	1725-266	1	piece
2CKA001754A4399	Cover frame 5gang titanium - alpha nea	1735-266	1	piece
2CKA001754A4355	Cover frame 5gang blue - Busch-axcent	1725-288	1	piece
2CKA001754A4769	Cover frame 5gang glass coral - Busch-axcent pur	1725-227	1	piece
2CKA001754A4579	Cover frame 5-gang(s) polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4759	Cover frame 5gang glass ocean - Busch-axcent pur	1725-228	1	piece
2CKA001754A4784	Cover frame 5gang glass oyster - Busch-axcent pur	1725-229	1	piece
2CKA001754A4692	Cover frame 5gang platinum - Busch-axcent pur	1725-270-500	1	piece
2CKA001754A4584	Cover frame 5-gang(s) antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4712	Cover frame 5gang black matt - Busch-axcent pur	1725-275-500	1	piece
2CKA001754A4594	Cover frame 5-gang(s) antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4702	Cover frame 5gang titanium - Busch-axcent pur	1725-276-500	1	piece
2CKA001754A4589	Cover frame 5-gang(s) antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4599	Cover frame 5-gang(s) antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4794	Cover frame 5gang paper brown - Busch-axcent pur	1725-243	1	piece
2CKA001754A4789	Cover frame 5gang paper blue - Busch-axcent pur	1725-248	1	piece
2CKA001754A4809	Cover frame 5gang slate grey - Busch-axcent pur	1725-290	1	piece
2CKA001754A4799	Cover frame 5gang concrete grey - Busch-axcent pur	1725-298	1	piece
2CKA001754A4122	Cover frame 5gang palladium - alpha exclusive	1725 KA-260	1	piece
2CKA001754A4123	Cover frame 5gang palladium - alpha exclusive	1735 KA-260	1	piece
2CKA001754A4408	Cover frame 5gang palladium - alpha nea	1735-260	1	piece

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Flush Mounted Inserts → Mechanical Inserts



Product image
not available